HUAYU® English

RM-L1130+8

Instruction for UNIVERSAL LCD/LED TV REMOTE CONTROLLER

Thank you for using our company remote controller products. When it is the first time to put in the batteries, please try it first. If it could work well with all of its functions, the product can be used directly without setup. If it could not work well, it should be set with the following methods before controlling your TV. This remote controller would not lose its memory when you change batteries, no need to reset.

Introduction:
RM-L1130+8 is the newest universal LCD/LED TV remote controller, Comprehensive care at different levels need, it can control old or new TV, famous brand or un-famous brand TV, nearly all models for TV.Commonly used functions and menu button all including. Easy setup, conveniently use, it is the best choice for your remote controller losing, damage, replacement, it will bring more convenient for your life.

Battery Installation
In accordance with the "+,-" symbols which is indicated inside the battery cabinet, open the cover and put into two new AAA (AAA) batteries (non-rationed), which is shown in the

Battery Description
●The remote controller is a low-power consume product, The lifetime of batteries is about 12 months under normal circumstances. If it is improperly used or operated, the lifetime would be shortened.
●Please do not put old and new batteries or different types of batteries together.
●In case of battery leakage, the batteries must be removed and the battery cabinet should be cleaned before putting into new batteries.
●You'd better remove the batteries

Methods for setting remote controller:

This remote controller has the following methods for setup , you can choose any of them.

****

A.Inputting code:
1, Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV. Find the three digits code from the code list.

2, Press "SET" button, then press "POWER" button, till the indicator lamp lights, then release the buttons, the remote controller will be in the state of inputting code.

3, Enter the first set of three-digit code in order. When you input each digit, the indicator lamp will flash one time, when you enter all of the three digits, the indicator lamp will turn off., setting to be finished. If the code is more than one set, please use first one at first.

4, Test other function buttons can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

B.Manually searching for the code:
1, Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV.

2, Press "SET" button, then press "POWER" button, till the indicator lamp lights, then release the button, the remote controller will be in the state of Manually searching for the code.

3, Press the "VOLUME+" button one time, the indicator lamp will flash one time, please pay attention to your TV, see the volume symbol appears on your TV or not, if not, please repeat this procedure.

4, Till the volume symbol appears on your TV, test other function buttons (except SET, POWER, and VOLUME button) can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

C.Automatically searching code:

1, Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV.

2, Press and hold the "SET"button for about 6 seconds, till the indicator lamp lights, the remote controller will enter automatic search state,please pay attention to your TV, see the volume symbol appears on your TV or not, if yes, please release "SET" button at once, set finished.

3, Test other function buttons (except SET, POWER, and VOLUME button) can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

D.Point to Point Brand Searching:
1, Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV. Find out the corresponding brand of your TV on this remote control, for example, SKYWORTHY = "0"

2, Press and hold the corresponding brand button for three seconds, the indicator lamp will flash, when the volume symbol appears on your TV, release button at once, the indicator lamp will turn off, set to be finished.

E.Restore factory Settings
Press "SET" button, then press "0", release the button, the indicator will flash two times, the remote controller restore factory Settings

Brand symbol table

PHILIPS	SANYO	SONY	TOSHIBA	SHARP	PANASONIC	SAMSUNG	LG
0	1	2	3	4	5	6	7
8	9	A	B	C	D	E	F
GRUNDIG	GOLDSTAR	SKYWORTHY	ORION	SUPRA	SAMTRON	TOPLINE	BLUE
10	11	12	13	14	15	16	17
18	19	1A	1B	1C	1D	1E	1F

****

Русский

А.Поиск нужной марки телевизора с помощью ввода кода вручную

1. Включите телевизор и в перечне кодов найдите тот, который соответствует марке Вашего телевизора.

2.Одновременно нажимайте кнопки "SET" и "POWER", пока не загорится индикаторная лампочка.

3. Введите три первых цифры кода, соответствующего модели телевизора. после ввода кода индикатор перестанет гореть, установка завершена

4. Проверьте работу кнопок на ПДУ. При наличии проблем повторно выполните процедуру настройки, начиная с шага 2.

В. Способ ручного поиска кода:

1. Включите телевизор и направьте на него пульт.

2. Одновременно нажимайте кнопки "SET" и "POWER", пока не загорится индикаторная лампочка.Тогда релиз, на этот раз в состоянии ручного поиска.

3. Нажмите кнопку "громкость +", затем освободите её, когда появится символ громкости, при каждом нажатии индикатор мигает один раз, если не появится символ громкости, повторите операцию.

4. После появления символа громкости проверьте другие кнопки (кроме кнопки настройки, кнопки питания, кнопки громкости). Если другие функции нормальны, нажмите кнопку "настройки", индикатор настройки гаснет, настройка выполнена.

С.Модели с функцией автоматического поиска

1, Включите телевизор и направьте на него пульт.

2. Удерживайте нажатой кнопку "SET", пока не загорится индикаторная лампочка. Индикаторная лампочка начнёт мигать.
Пульт активизировал функцию автоматического поиска. Внимательно смотрите на экран телевизора, не отпуская кнопку "SET". Введите три первых цифры кода, соответствующего модели телевизора.

3, Проверьте работу кнопок на ПДУ(Установите кнопку, кнопка питания, клавиши регулировки громкости, кроме) . При наличии проблем повторно выполните процедуру настройки, начиная с шага 2.

D.
1, Найдите код, соответствующий модели вашего телевизора.
Например, для SKYWORTHY – это «0». Включите телевизор и направьте на него пульт.

2, Удерживайте нажатой кнопку кода, пока не загорится индикаторная лампочка (около 3 секунд). Не отпускайте кнопку,
и индикаторная лампочка начнёт мигать. Активизировался режим поиска кода.
Когда на экране появится символ громкости, отпустите кнопку кода. Индикаторная лампочка погаснет
Проверьте работу кнопок на ПДУ. При наличии проблем повторно выполните процедуру настройки, начиная с шага 2

4, Проверьте работу кнопок на ПДУ. При наличии проблем повторно выполните процедуру настройки, начиная с шага 2.

Сравнительная таблица символов марки

PHILIPS	SANYO	SONY	TOSHIBA	SHARP	PANASONIC	SAMSUNG	LG
0	1	2	3	4	5	6	7
8	9	A	B	C	D	E	F
GRUNDIG	GOLDSTAR	SKYWORTHY	ORION	SUPRA	SAMTRON	TOPLINE	BLUE
10	11	12	13	14	15	16	17
18	19	1A	1B	1C	1D	1E	1F

****

Español

A.Ingresa el código
1, Encender el televisor , apunte el control remoto hacia televisor. luego encontrar el correspondiente código de tres dígitos de la marca correspondiente en la tabla de códigos

2, Presiona al mismo tiempo el botón SET y POWER , hasta la luz indicador se enciende, luego suelta el botón por lo que se convierte en el estado de entrada de código

3, Ingresar primer conjunto de código de tres dígito. cada vez que un dígito es la entrada, la luz de indicación parpadea una vez, despúes que todos los 3 dígitos ha ingresado , la luz de indicador estaria apagado, si el código es más de un conjunto. por favor, utilice la primera.

4, prueba si otros botones de función podría funcionar bien, como el botón de silencio (mute)
si no, repita los pasos 2 hasta que encuentre un conjunto de código adecuado.

B.La búsqueda manual del código

1, Encender el televisor apunte el control remoto hacia televisor.

2, Presiona al mismo tiempo el botón SET y POWER , hasta la luz indicador se enciende, luego suelta el botón por lo que se convierte en el estado de entrada de código

3, presione el botón de volumen + una vez y luego suéltelo. ver si el símbolo de volumen aparece en la pantalla de TV, si no se produce tal símbolo, repita el procedimiento.

4, Después de que el símbolo de volumen aparece, pruebe otro botón de función (excepto el ajuste(SET), POWER, VULUMEN),si bien el trabajo, pulse el botón de ajuste inmediato y la luz de indicación se apagará , lo que significa que la configuración se ha terminado.

C.La búsqueda automatica del códigos.

1, Encender el televisor , apunte el control remoto hacia televisor.

2.Presione y mantenga el botón de ajuste(SET)durante unos 6 segundos hasta la luz indicador se enciende. Ver si el símbolo de volumen aparece en la pantalla ,si es así,suelte de inmediato el botón SET para detener la busqueda automatica

3, pruebe otro botón de función (excepto el ajuste (SET), POWER, VULUMEN), si bien el trabajo, pulse el botón de ajuste inmediato y la luz de indicación se apagará , lo que significa que la configuración se ha terminado. si no, repita los pasos 2 hasta que encuentre el código adecuado.

D.Mode de búsqueda de punto a punto

1, Encender el televisor manualmente, apunte el mando a distancia hacia el televisor, busque la marca correspondiente de TV, tal como SKYWORTHY con su símbolo 0.

2, pulsada botón de símbolo de marco correspondiente,durante unos 3 segundos no suelte el botón hasta que la luz indicador parpadea, Cuando aparece el símbolo de volumen en la pantalla de TV, suelte inmediatamente el botón, y la luz de indicador apagará. Probar si el contro remoto funciona bien , si no, repita el procedimientos.

La table de symbole correspondant à la marque

PHILIPS	SANYO	SONY	TOSHIBA	SHARP	PANASONIC	SAMSUNG	LG
0	1	2	3	4	5	6	7
8	9	A	B	C	D	E	F
GRUNDIG	GOLDSTAR	SKYWORTHY	ORION	SUPRA	SAMTRON	TOPLINE	BLUE
10	11	12	13	14	15	16	17
18	19	1A	1B	1C	1D	1E	1F

B0063798

E.Restaurar los ajustes de fábrica
Pulse el botón "SET", después pulse el número 0, la liberación, el indicador parpadea dos veces, restablecer la configuración de fábrica

****

Warm Tips
If you have any problems when you set or use this remote controller, please try to do as follow:
◆ When you set this remote controller, please do according to the steps of the method "inputting code". If it can't control your device, Please input the other codes according to sequence.
◆ If you have input wrong codes, but the indicator still light, you just need to input the correct code. If the indicator turn off, you need to reset from step 1.
◆ whe you use the method "Manually searching for the code", because the codes are too much, you need to wait patiently

Technical parameters
● Remote Controlling Distance: About 8 meters (varies by different types)
● Battery Type: two pieces of AAA Batteries
After-sales Service
If the remote controller has problems or could not be used temporarily, please contact our company as soon as possible. We would make efforts to offer you with best services. But do not disassemble or repair it by yourself. We would not be responsible for remote controllers that have been disassembled without authorization.

To ensure that you could enjoy good after-sales service, please keep the shopping bills or receipts when buying the product.

The Company reserves the final interpretation of this specification. The design and technical parameters could be changed without notice.



B0063790